



Assembly instructions for universal lift light for 4 pillar lift

Content List:

LED luminaire 120 cm./18w.	6 pcs.
Aluminum Bracket	6 set
Multi Bracket – Angle: 90°	12 pcs.
Pop Rivets	12 pcs.

Self-tapping screws	12 pcs.
Start plug 100cm.	1 pcs.
Cable 300cm.	2 pcs.
End Cap	1 pcs.



1. Secure the 12 angle brackets on each side of the lift, so they will fit with the three luminaires. Drill a 5 mm hole in the lift and secure the angle bracket on to the lift with pop rivets.
2. Take the luminaires out of the box and attach three on each side. Secure with a little Philips screwdriver. Notice, direction male-plug against power connection and about.
3. Connect the three luminaires in the bottom on each side. Notice, the track for correct assembling of male/female plug.



4. Connect the two sides with one 3-meter cable – in the front of the lift. Again notice, track for correct assembling of he and female plug.
5. Attach the power supply cable on the luminaire and plug the plug in the socket. Insert the extra 3-meter wire as needed. If you wish to install in a power strip, the plug can be cut off and the wires will be mounted in the box.
- **IMPORTANT: This installation must be done by an authorized electrician.**
6. Attach the end cap.
7. Turn on the power! Enjoy your **RNS LIFT-LIGHT!** If you have any questions regarding the installation you are always welcome to call us. We are always ready to help.